

Kit 1039


AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04

AUDI S6, 4-dr Sedan, 99-03 / *98-04



AUDI A6 Avant, 5-dr Estate, 98-04

AUDI A6, 5-dr Wagon, *99-05


*North America



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

754 Rapid System




754 Rapid System

480R Rapid Traverse (North America)


480R Rapid Traverse (North America)

480R Rapid Traverse (North America)

480R Rapid Traverse (North America)

Europe		North America	
	     	     	     



1




2




754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)





x4

3



754 Rapid System



	X
AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04	34,5
AUDI S6, 4-dr Sedan, 99-03 / *98-04	34,5
AUDI A6 Avant, 5-dr Estate, 98-04	34
AUDI A6, 5-dr Wagon, *99-05	34

	Y
AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04	34,5
AUDI S6, 4-dr Sedan, 99-03 / *98-04	34,5
AUDI A6 Avant, 5-dr Estate, 98-04	32
AUDI A6, 5-dr Wagon, *99-05	32

3





480R Rapid Traverse



480 Traverse




(North America)



	X inch	X mm
AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04	39 1/4"	996 mm
AUDI S6, 4-dr Sedan, 99-03 / *98-04	39 1/4"	996 mm
AUDI A6 Avant, 5-dr Estate, 98-04	39"	991 mm
AUDI A6, 5-dr Wagon, *99-05	39"	991 mm

	Y inch	Y mm
AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04	39 1/4"	996 mm
AUDI S6, 4-dr Sedan, 99-03 / *98-04	39 1/4"	996 mm
AUDI A6 Avant, 5-dr Estate, 98-04	38 1/4"	971 mm
AUDI A6, 5-dr Wagon, *99-05	38 1/4"	971 mm


4



5



AUDI A6, 4-dr Sedan, 97-00, 01-03 / *98-04

AUDI S6, 4-dr Sedan, 99-03 / *98-04




AUDI A6 Avant, 5-dr Estate, 98-04


AUDI A6, 5-dr Wagon, *99-05




6








i




A



B



7



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно





CZ Pokręťta багажníka dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmenično zategnite
HU Egymástól függetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชั่วในแบบสลับ




≈ 3 Nm





8



x1
17 mm





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA **510** (x10)

EUR **452** (x12)

ASIA