




Kit 1255

HYUNDAI Lavita, 5-dr MPV, 01–
 HYUNDAI Matrix, 5-dr MPV, 01–
 HYUNDAI FC, 5-dr MPV, 01–



480R
754



480



750



THULE[®]
SWEDEN

**Max.
75kg**
**Max.
165 lbs**

Kit XXXX
instructions

x1

x4

x4

x4

x4

480R/754

x1

x4

x4

x4

x4

480

x1

x4

x4

x4

750

x2 x2 x2 x4	x2	x2 x2 x4 x4	x2 x2 x2	x2
----------------------	----	----------------------	----------------	----






100 x 2

266 x 2


06 x 4

x 1


Kit



3





754



750



1





2




	X
HYUNDAI Lavita, 5-dr MPV, 01-	37,5
HYUNDAI Matrix, 5-dr MPV, 01-	37,5
HYUNDAI FC, 5-dr MPV, 01-	37,5

1



2



	Y
HYUNDAI Lavita, 5-dr MPV, 01-	36
HYUNDAI Matrix, 5-dr MPV, 01-	36
HYUNDAI FC, 5-dr MPV, 01-	36




480R



480

1




2




	X inch	X mm
HYUNDAI Lavita, 5-dr MPV, 01-	40 $\frac{3}{8}$ "	1026 mm
HYUNDAI Matrix, 5-dr MPV, 01-	40 $\frac{3}{8}$ "	1026 mm
HYUNDAI FC, 5-dr MPV, 01-	40 $\frac{3}{8}$ "	1026 mm

1



2










	Y inch	Y mm
HYUNDAI Lavita, 5-dr MPV, 01-	39 $\frac{3}{4}$ "	1011 mm
HYUNDAI Matrix, 5-dr MPV, 01-	39 $\frac{3}{4}$ "	1011 mm
HYUNDAI FC, 5-dr MPV, 01-	39 $\frac{3}{4}$ "	1011 mm

4


HYUNDAI Lavita, 5-dr MPV, 01–

HYUNDAI Matrix, 5-dr MPV, 01–





HYUNDAI FC, 5-dr MPV, 01–



5



	X mm	Y mm	X inch	Y inch
HYUNDAI Lavita, 5-dr MPV, 01–	410 mm	700 mm	16 1/8"	27 1/2"
HYUNDAI Matrix, 5-dr MPV, 01–	410 mm	700 mm	16 1/8"	27 1/2"
HYUNDAI FC, 5-dr MPV, 01–	410 mm	700 mm	16 1/8"	27 1/2"



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokrétla багажника dokręcaj naprzemiennie.
SK Doťahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egy mástól függetlenül szorítandó
GR Σφιγγείτε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชันในแบบสลับ


6







480R/754








480



750





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		544 (x4)
		596 (x6)
		588 (x8)
NA		510 (x10)
EUR		452 (x12)
ASIA		