

Kit 1292

FORD Ranger, 2-dr Single Cab, 98-02, 03-11

FORD Ranger, 2-dr Super Cab, *98-11

FORD Ranger, 4-dr Double Cab, 98-02, 03-11

FORD Ranger, 4-dr Super Cab, 98-02, 03-11

MAZDA B-Series, 2-dr Single Cab, 98-06

MAZDA B-Series, 3-dr Extended Cab, *98-06

MAZDA B-Series, 4-dr Double Cab, 98-06

MAZDA B-Series, 4-dr Extended Cab, *98-06


MAZDA BT-50, 2-dr Single Cab, 07-11

MAZDA BT-50, 4-dr Crew Cab, 07-11



MAZDA BT-50, 4-dr Double Cab, 07-11

MAZDA Freestyle, 4-dr Maxi Cab, 03-11

*North America



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

ISO 11154-E

Herbály Autó www.herbalyauto.hu

The diagram illustrates the importance of reading instructions. It features a box labeled 'THULE' with a warning triangle and a plus sign next to a box labeled 'instructions' with a warning triangle and a plus sign. A person is shown reading a document.

754 Rapid System

480R Rapid Traverse (North America)



754 Rapid System

480R Rapid Traverse (North America)


480 Rapid Traverse (North America)

480 Rapid Traverse (North America)

480 Rapid Traverse (North America)

Europe		North America	
	 x2	 x1	 x2
 x2	 x2	 x2	 x2
 x2	 x2	 x2	 x2
 x2	 x2	 x2	 x2
 x2	 x2	 x2	 x2
 x2	 x2	 x2	 x2



1






2






754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3




754 Rapid System



X


FORD Ranger , 2-dr Single Cab, 98-02, 03-11	33
FORD Ranger , 2-dr Super Cab, *98-11	33
FORD Ranger , 4-dr Double Cab, 98-02, 03-11	32,5
FORD Ranger , 4-dr Super Cab, 98-02, 03-11	32,5
MAZDA B-series , 2-dr Single Cab, 98-06	33
MAZDA B-series , 3-dr Extended Cab, *98-06	33
MAZDA B-series , 4-dr Double Cab, 98-06	32,5
MAZDA B-series , 4-dr Extended Cab, *98-06	32,5
MAZDA BT-50 , 2-dr Single Cab, 07-11	33,5
MAZDA BT-50 , 4-dr Crew Cab, 07-11	33,5
MAZDA BT-50 , 4-dr Double Cab, 07-11	33,5
MAZDA Freestyle , 4-dr Maxi Cab, 03-11	32,5



Y

FORD Ranger , 2-dr Single Cab, 98-02, 03-11	-
FORD Ranger , 2-dr Super Cab, *98-11	-
FORD Ranger , 4-dr Double Cab, 98-02, 03-11	32,5
FORD Ranger , 4-dr Super Cab, 98-02, 03-11	32,5
MAZDA B-series , 2-dr Single Cab, 98-06	-
MAZDA B-series , 3-dr Extended Cab, *98-06	-
MAZDA B-series , 4-dr Double Cab, 98-06	32,5
MAZDA B-series , 4-dr Extended Cab, *98-06	32,5
MAZDA BT-50 , 2-dr Single Cab, 07-11	-
MAZDA BT-50 , 4-dr Crew Cab, 07-11	32,5
MAZDA BT-50 , 4-dr Double Cab, 07-11	32,5
MAZDA Freestyle , 4-dr Maxi Cab, 03-11	32,5


4




3

480R Rapid Traverse


480 Traverse

(North America)


	X inch	X mm
FORD Ranger , 2-dr Single Cab, 98-02, 03-11	38 $\frac{5}{8}$ "	981 mm
FORD Ranger , 2-dr Super Cab, *98-11	38 $\frac{5}{8}$ "	981 mm
FORD Ranger , 4-dr Double Cab, 98-02, 03-11	38 $\frac{3}{8}$ "	976 mm
FORD Ranger , 4-dr Super Cab, 98-02, 03-11	38 $\frac{3}{8}$ "	976 mm
MAZDA B-series , 2-dr Single Cab, 98-06	38 $\frac{5}{8}$ "	981 mm
MAZDA B-series , 3-dr Extended Cab, *98-06	38 $\frac{5}{8}$ "	981 mm
MAZDA B-series , 4-dr Double Cab, 98-06	38 $\frac{7}{8}$ "	986 mm
MAZDA B-series , 4-dr Extended Cab, *98-06	38 $\frac{7}{8}$ "	986 mm
MAZDA BT-50 , 2-dr Single Cab, 07-11	38 $\frac{7}{8}$ "	986 mm
MAZDA BT-50 , 4-dr Crew Cab, 07-11	38 $\frac{7}{8}$ "	986 mm
MAZDA BT-50 , 4-dr Double Cab, 07-11	38 $\frac{7}{8}$ "	986 mm
MAZDA Freestyle , 4-dr Maxi Cab, 03-11	38 $\frac{3}{8}$ "	976 mm



	Y inch	Y mm
FORD Ranger , 2-dr Single Cab, 98-02, 03-11	-	-
FORD Ranger , 2-dr Super Cab, *98-11	-	-
FORD Ranger , 4-dr Double Cab, 98-02, 03-11	38 $\frac{3}{8}$ "	976 mm
FORD Ranger , 4-dr Super Cab, 98-02, 03-11	38 $\frac{3}{8}$ "	976 mm
MAZDA B-series , 2-dr Single Cab, 98-06	-	-
MAZDA B-series , 3-dr Extended Cab, *98-06	-	-
MAZDA B-series , 4-dr Double Cab, 98-06	38 $\frac{3}{8}$ "	976 mm
MAZDA B-series , 4-dr Extended Cab, *98-06	38 $\frac{3}{8}$ "	976 mm
MAZDA BT-50 , 2-dr Single Cab, 07-11	-	-
MAZDA BT-50 , 4-dr Crew Cab, 07-11	38 $\frac{3}{8}$ "	976 mm
MAZDA BT-50 , 4-dr Double Cab, 07-11	38 $\frac{3}{8}$ "	976 mm
MAZDA Freestyle , 4-dr Maxi Cab, 03-11	38 $\frac{3}{8}$ "	976 mm

4


5


FORD Ranger, 2-dr Single Cab, 98-02, 03-11

FORD Ranger, 2-dr Super Cab, *98-11

MAZDA B-series, 2-dr Single Cab, 98-06

MAZDA B-series, 3-dr Extended Cab, *98-06

MAZDA BT-50, 2-dr Single Cab, 07-11



FORD Ranger, 4-dr Double Cab, 98-02, 03-11

FORD Ranger, 4-dr Super Cab, 98-02, 03-11


MAZDA B-series, 4-dr Double Cab, 98-06

MAZDA B-series, 4-dr Extended Cab, *98-06

MAZDA BT-50, 4-dr Crew Cab, 07-11

MAZDA BT-50, 4-dr Double Cab, 07-11







MAZDA Freestyle, 4-dr Maxi Cab, 03-11




A

B


C




6





	X mm	Y mm	X inch	Y inch
FORD Ranger, 2-dr Single Cab, 98-02, 03-11	320 mm	-	12 ⁵ / ₈ "	-
FORD Ranger, 2-dr Super Cab, *98-11	320 mm	-	12 ⁵ / ₈ "	-
MAZDA B-series, 2-dr Single Cab, 98-06	320 mm	-	12 ⁵ / ₈ "	-
MAZDA B-series, 3-dr Extended Cab, *98-06	320 mm	-	12 ⁵ / ₈ "	-
MAZDA BT-50, 2-dr Single Cab, 07-11	320 mm	-	12 ⁵ / ₈ "	-



	X mm	Y mm	X inch	Y inch
FORD Ranger, 4-dr Double Cab, 98-02, 03-11	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
FORD Ranger, 4-dr Super Cab, 98-02, 03-11	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
MAZDA B-series, 4-dr Double Cab, 98-06	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
MAZDA B-series, 4-dr Extended Cab, *98-06	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
MAZDA BT-50, 4-dr Crew Cab, 07-11	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
MAZDA BT-50, 4-dr Double Cab, 07-11	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "
MAZDA Freestyle, 4-dr Maxi Cab, 03-11	320 mm	750 mm	12 ⁵ / ₈ "	29 ¹ / ₂ "






7







GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievelciēt pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно



CZ Pokrétla багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenočno zategnite
HU Egyarástól függetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ซักนแบบสลับ








≈ 3 Nm

















≈ 3 Nm




CZ Pokrétla bagazníka dokrécaj dokrécaj naprzemienie.
SK Dotahujúce striedavo
SLO Privlačje izmenično.
HU Naizmjenično zategnitie
HR Egymástól függetlenül
 szorítandó
GR Σφιγγυστε εναλλάξ
TR Dönüşümlü sıkın
中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย หมุนสลับกัน

GB/US Tighten alternately
D Die Schrauben abwechselnd
 anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de
 rechterkant aandraaien
I Alternare il serraggio delle viti
E Aprelar alternativamente
PT Aprelar alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pievecliet pamēbus
LIT Užsukinėkite pakaitomis
PL Sruby dokrécaj naprzemienie
RU Затягивайте попеременно













FORD Ranger, 4-dr Double Cab, '98-02, 03-11	320 mm	750 mm	12 5/8"	29 1/2"
FORD Ranger, 4-dr Super Cab, '98-02, 03-11	320 mm	750 mm	12 5/8"	29 1/2"
MAZDA B-series, 4-dr Double Cab, '98-06	320 mm	750 mm	12 5/8"	29 1/2"
MAZDA B-series, 4-dr Extended Cab, '98-06	320 mm	750 mm	12 5/8"	29 1/2"
MAZDA BT-50, 4-dr Crew Cab, '07-11	320 mm	750 mm	12 5/8"	29 1/2"
MAZDA BT-50, 4-dr Double Cab, '07-11	320 mm	750 mm	12 5/8"	29 1/2"
MAZDA Freestyle, 4-dr Maxi Cab, 03-11	320 mm	750 mm	12 5/8"	29 1/2"



FORD Ranger, 2-dr Single Cab, '98-02, 03-11	320 mm	-	12 5/8"	-
FORD Ranger, 2-dr Super Cab, '98-11	320 mm	-	12 5/8"	-
MAZDA B-series, 2-dr Single Cab, '98-06	320 mm	-	12 5/8"	-
MAZDA B-series, 3-dr Extended Cab, '98-06	320 mm	-	12 5/8"	-
MAZDA BT-50, 2-dr Single Cab, '07-11	320 mm	-	12 5/8"	-




6



A

B

C



FORD Ranger, 4-dr Double Cab, 98-02, 03-11

FORD Ranger, 4-dr Super Cab, 98-02, 03-11

MAZDA B-series, 4-dr Double Cab, 98-06

MAZDA B-series, 4-dr Extended Cab, 98-06

MAZDA BT-50, 4-dr Crew Cab, 07-11

MAZDA BT-50, 4-dr Double Cab, 07-11

MAZDA Freestyle, 4-dr Maxi Cab, 03-11

MAZDA BT-50, 2-dr Single Cab, 07-11

MAZDA B-series, 3-dr Extended Cab, 98-06


MAZDA B-series, 2-dr Single Cab, 98-06

FORD Ranger, 2-dr Super Cab, 98-11


FORD Ranger, 2-dr Single Cab, 98-02, 03-11

5



3




2




FORD Ranger, 2-dr Single Cab, 98-02, 03-11	38 5/8"	981 mm
FORD Ranger, 2-dr Super Cab, *98-11	38 3/4"	976 mm
FORD Ranger, 4-dr Double Cab, 98-02, 03-11	38 3/4"	976 mm
FORD Ranger, 4-dr Super Cab, 98-02, 03-11	38 3/8"	976 mm
MAZDA B-series, 2-dr Single Cab, 98-06	38 5/8"	981 mm
MAZDA B-series, 3-dr Extended Cab, *98-06	38 5/8"	981 mm
MAZDA B-series, 4-dr Double Cab, 98-06	38 7/8"	986 mm
MAZDA B-series, 4-dr Extended Cab, *98-06	38 7/8"	986 mm
MAZDA BT-50, 2-dr Single Cab, 07-11	38 7/8"	986 mm
MAZDA BT-50, 4-dr Crew Cab, 07-11	38 7/8"	986 mm
MAZDA BT-50, 4-dr Double Cab, 07-11	38 7/8"	986 mm
MAZDA Freestyle, 4-dr Maxi Cab, 03-11	38 3/8"	976 mm






2






FORD Ranger, 2-dr Single Cab, 98-02, 03-11	-	-
FORD Ranger, 2-dr Super Cab, *98-11	-	-
FORD Ranger, 4-dr Double Cab, 98-02, 03-11	38 3/8"	976 mm
FORD Ranger, 4-dr Super Cab, 98-02, 03-11	38 3/8"	976 mm
MAZDA B-series, 2-dr Single Cab, 98-06	-	-
MAZDA B-series, 3-dr Extended Cab, *98-06	-	-
MAZDA B-series, 4-dr Double Cab, 98-06	38 3/8"	976 mm
MAZDA B-series, 4-dr Extended Cab, *98-06	38 3/8"	976 mm
MAZDA BT-50, 2-dr Single Cab, 07-11	-	-
MAZDA BT-50, 4-dr Crew Cab, 07-11	38 3/8"	976 mm
MAZDA BT-50, 4-dr Double Cab, 07-11	38 3/8"	976 mm
MAZDA Freestyle, 4-dr Maxi Cab, 03-11	38 3/8"	976 mm




4











2



1




instructions


Kit 1292

- FORD Ranger, 2-dr Single Cab, 98-02, 03-11
- FORD Ranger, 2-dr Super Cab, *98-11
- FORD Ranger, 4-dr Double Cab, 98-02, 03-11
- FORD Ranger, 4-dr Super Cab, 98-02, 03-11
- MAZDA B-series, 2-dr Single Cab, 98-06
- MAZDA B-series, 3-dr Extended Cab, *98-06
- MAZDA B-series, 4-dr Double Cab, 98-06
- MAZDA B-series, 4-dr Extended Cab, *98-06
- MAZDA BT-50, 2-dr Single Cab, 07-11
- MAZDA BT-50, 4-dr Crew Cab, 07-11
- MAZDA BT-50, 4-dr Double Cab, 07-11
- MAZDA Freestyle, 4-dr Maxi Cab, 03-11

*North America



480R
754



THULE
SWEDEN
PROFESSIONAL

ISO 11154-E