



Kit 1350



TOYOTA Hilux, 4-dr Double Cab, 05-15

TOYOTA Vigo, 4-dr Double Cab, 04-15



480R
754



480



750



THULE[®]
SWEDEN

**Max.
50kg**
**Max.
110 lbs**

THULE
Kit XXXX
instructions

480R/754

480

750

x2
x2
x2
x4

x2

x2
x2
x4
x4

x2
x2
x2

x2

232 **x2**

944 **x2**






23 **x1**

24 **x1**


06 **x2**

x1


Kit



3





754



750



1




2



X

TOYOTA Hilux, 4-dr Double Cab, 05-15	41,5
TOYOTA Vigo, 4-dr Double Cab, 04-15	41,5

1



2



Y

TOYOTA Hilux, 4-dr Double Cab, 05-15	42
TOYOTA Vigo, 4-dr Double Cab, 04-15	42




480R




480

1




2




X inch/mm

X inch	X mm
TOYOTA Hilux, 4-dr Double Cab, 05-15	42" 1066 mm
TOYOTA Vigo, 4-dr Double Cab, 04-15	42" 1066 mm

1



2
















Y inch/mm

Y inch	Y mm
TOYOTA Hilux, 4-dr Double Cab, 05-15	42 1/8" 1071 mm
TOYOTA Vigo, 4-dr Double Cab, 04-15	42 1/8" 1071 mm


4

TOYOTA Hilux, 4-dr Double Cab, 05-15




TOYOTA Vigo, 4-dr Double Cab, 04-15



5



	X mm	Y mm	X inch	Y inch
TOYOTA Hilux, 4-dr Double Cab, 05-15	250 mm	720 mm	9 7/8"	28 3/8"
TOYOTA Vigo, 4-dr Double Cab, 04-15	250 mm	720 mm	9 7/8"	28 3/8"



GB/US	Tighten alternately	CZ	Pokrétla bagażnika dokręcaj dokręcaj naprzemiennie.
D	Die Schrauben abwechselnd anziehen	SK	Dofahujte striedavo
F	Serrer alternativement chaque côté	SLO	Privijajte izmenično.
NL	Afwisselend aan de linker- en de rechterkant aandraaien	HR	Naizmjenično zategnite
I	Alternare il serraggio delle viti	HU	Egymástól függetlenül szorítandó
E	Apretar alternativamente	GR	Σφιγγετε εναλλάξ
PT	Aperte alternadamente	TR	Dönüşümlü sıkın
S	Dra åt växelvis	中文	交替拧紧
FIN	Kierrä vuorotellen	한국어	번갈아 가며 조이십시오.
EST	Pinguldage vaheldumisi	日本語	交互に締め付けてください。
LAT	Pievelciēt pamišus	ไทย	ขันในแบบสลับ
LIT	Užsukinėkite pakaitomis		
PL	Śruby dokręcaj naprzemiennie		
RU	Затягивайте попеременно		






6





480R/754



480



750




i




1




2




i




1




2




i








1



2





THULE®
SWEDEN

**ONE
KEY
SYSTEM**

		544	(x4)
		596	(x6)
		588	(x8)
NA		510	(x10)
EUR		452	(x12)
ASIA			








www.thuleprofessional.com







info@thule.com
customer.service@thule.com



Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA
Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN










GB/US Tighten alternately
D Die Schrauben abwechselnd
anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de
I Altermare il serraggio delle viti
E Aperte alternativamente
PT Aperte alternativamente
S Draai vóórwaarts
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pielieciet pamāšus
LT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно












CZ Pořadí bagazníka dokręcaj
SK Dotiahnuť striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategniti
HU Atyváltanul szorítandó
GR Σφίγγετε εναλλάξ
TR Dönüşümü skin
中文 交替拧紧
한국어 좌우에 교대로 조이십시오.
日本語 交互に締め付けてください。









TOYOTA Hilux, 4-dr Double Cab, 05-15		250 mm	720 mm
TOYOTA Vigo, 4-dr Double Cab, 04-15		250 mm	720 mm
X mm	Y mm	X inch	Y inch
9 7/8"	28 3/8"	9 7/8"	28 3/8"





6





480R/754





TOYOTA Hilux, 4-dr Double Cab, 05-15
TOYOTA Vigo, 4-dr Double Cab, 04-15















2



1

Kit




instructions

ISO 11154-E



PROFESSIONAL

THULE
SWEDEN®

750



480R
754



TOYOTA Hilux, 4-dr Double Cab, 05-15
TOYOTA Vigo, 4-dr Double Cab, 04-15

Kit 1350