





Thule Rapid System Kit 1477

> Instructions

MITSUBISHI Lancer, 4-dr Sedan, 08–

MITSUBISHI Lancer, 5-dr Hatchback, 08–



ISO 11154-E

141477


C.20121010
519-1477-01

Herbály Autó www.herbalyauto.hu

Bring your life
thule.com



120 x1



121 x1

176 x1

177 x1




962 x2



963 x2






x1



x1

1



	X (scale)	X (mm)	X (inch)
MITSUBISHI Lancer , 4-dr Sedan, 08-	37,5	1026	40 ³ / ₈
MITSUBISHI Lancer , 5-dr Hatchback, 08-	37,5	1026	40 ³ / ₈





	Y (scale)	Y (mm)	Y (inch)
MITSUBISHI Lancer , 4-dr Sedan, 08-	33	981	38 ⁵ / ₈
MITSUBISHI Lancer , 5-dr Hatchback, 08-	33	981	38 ⁵ / ₈

2

MITSUBISHI Lancer, 4-dr Sedan, 08-
MITSUBISHI Lancer, 5-dr Hatchback, 08-



3



	W (mm)	Z (mm)	W (inch)	Z (inch)
MITSUBISHI Lancer , 4-dr Sedan, 08–	265	715	10 ³/₈	28 ¹/₈
MITSUBISHI Lancer , 5-dr Hatchback, 08–	265	715	10 ³/₈	28 ¹/₈

