


Kit 1611

FIAT 500, 3-dr Hatchback, 07-*



FIAT 500, 3-dr Hatchback, 11-**

***Without glass roof**


****North America, Without glass roof**



480R Rapid Traverse
754 Rapid System





480 Traverse





THULE®
SWEDEN


ISO 11154-E


 + 7 kg / 15,4 lbs = **Max. 50 kg**
 3 kg / 6,6 lbs = **Max. 110 lbs**







 + 





x1



x4


x4


x4

480R Rapid Traverse
754 Rapid System













x1


x4



x4



x4


480 Traverse

					
 x2	 x2 23 mm	 x1 17 mm	 x2 23 mm	 x2	 x2
	 x2	 x2 23 mm	 x2		
	 x4	 x2	 x4		
	 x4				




1099 x2


932 x2


137 x4


x1

Kit


1




480R Rapid Traverse
754 Rapid System



480 Traverse










2




480R Rapid Traverse
754 Rapid System



480 Traverse





3




754 Rapid System

1





2




	X
FIAT 500, 3-dr Hatchback, 07-*	33,5
FIAT 500, 3-dr Hatchback, 11-**	33,5

1



2



	Y
FIAT 500, 3-dr Hatchback, 07-*	28
FIAT 500, 3-dr Hatchback, 11-**	28




480R Rapid Traverse




480 Traverse

1




2




	X inch	X mm
FIAT 500, 3-dr Hatchback, 07-*	38 $\frac{7}{8}$ "	986 mm
FIAT 500, 3-dr Hatchback, 11-**	38 $\frac{7}{8}$ "	986 mm

1




2



	Y inch	Y mm
FIAT 500, 3-dr Hatchback, 07-*	36 $\frac{5}{8}$ "	931 mm
FIAT 500, 3-dr Hatchback, 11-**	36 $\frac{5}{8}$ "	931 mm








4




FIAT 500, 3-dr Hatchback, 07-*

FIAT 500, 3-dr Hatchback, 11-**




SRA



5



	X mm	Y mm	Z mm	X inch	Y inch	Z inch
FIAT 500, 3-dr Hatchback, 07-*	225 mm	600 mm	350 mm	8 7/8"	23 5/8"	13 3/4"
FIAT 500, 3-dr Hatchback, 11-**	225 mm	600 mm	350 mm	8 7/8"	23 5/8"	13 3/4"



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Apretar alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pievelciēt pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokrétla багаžníka dokręcaj dokręcaj naprzemiennie.

SK Dotahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól fűggetlenül szorítandó

GR Σφιγγείτε εναλλάξ

TR Dönüşümlü sıkın






中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชนในแบบสลับ

6



7

